



1



2



3



M.A.D'2

1

FUNCTIONS

A Hours
B Minutes

2

WINDING

Your watch is equipped with an automatic movement. If it has stopped, wind the movement by turning the crown several times clockwise.

3

TIME-SETTING

Pull the crown all the way “out” to the second position and rotate to set the time. The time can be set forwards or backwards by rotating clockwise or anti-clockwise. Push the crown back against the case when finished.